





PAD-SHFS

CTA DIGITAL


Heavy-Duty Security Gooseneck Floor Stand for 7-13 Inch Tablets

INSTRUCTION MANUAL

****Note** - Hinges may get looser and droop over time. Please tighten screws for optimum usage and efficiency.




Attachable
battery-pack
cradle



Attachable and
detachable
swivel casters




Adjustable holder
for tablets 7 - 13
inches



Ultra-flexible and
sturdy gooseneck

Package Contents:



Instructions:

1.Going the Cable Through the Cable Routings on the Pole

This product allows you to go through the cable from the cable routings on the pole.



1.Put the top pole to the lowest position,insert the cable into the cable routing on the bottom pole and push inward.




2.Draw out the top pole and continue to push inward the cable until the cable head is visible through the cable routing on the top pole .




3.Draw out the cable head from the cable routing on the top pole .

2.Stand Assembly:




Attaching wheels:


Connect wheels to stand base before attaching pole.




Screw wheels into floor base by hand,
then use wrench to tighten.




3.Connecting the Gooseneck Tablet Holder & Battery Case



1. Place battery case over metal
connection on the pole.




2.Place gooseneck over metal connection
then turn clockwise to screw down until tight.




3.Use the smaller Star Allen key to tighten the
small star meter screw inside the gooseneck.
*Note: if meter screw is already in, unscrew
before attaching gooseneck in step 2.*


4. Installing your Device and Adjusting the Tablet Holder



4.Expand tablet holder to fit tablet at corners where
it doesn't obstruct tablet camera and push together
until it's a tight fit.



5. Use provided foam pads to adjust your
device's fit onto the holder.



6.Rotate plastic grip counter-clockwise
to loosen, then adjust pole to desired
height. Rotate plastic grip clockwise to
tighten.