



CTA DIGITAL

Dual Security Gooseneck Kiosk Stand with Locking Case and Anti-Theft Cable for iPad, iPad Air, and iPad Pro 9.7


INSTRUCTION MANUAL

PAD-DSGK

Please follow the guidelines and instructions as laid out in this instruction manual.



Package Contents



(2) Nuts with bolts




(2) Screws

1) Screw the gooseneck to the base using the Allen key provided. (now see cable management is using a charger.)



2) Insert the connector of the Case into the Gooseneck, align the screw hole and marker, then tighten the screw by using the Allen key




Inserting Your Tablet

1) With the stand stable and the case in a flat orientation, open the case door and set your iPad down in the case tray. Use foam inserts for iPad Air, iPad Pro 9.7, and iPad(2017).



2) Close the case door, then insert the key into the lock and turn.

Anti-Theft Cable




Using the Cable Management System



Remove the connector from the Gooseneck and then let the cable through the Base and the Gooseneck.



Let the cable through the cable outlet on the Gooseneck



Slide protector over the cable and put the protector into the hole on the Base